



# LPCXpresso

## Getting started with NXP LPCXpresso

Rev. 11 — 14 June 2011

User guide

### Document information

Info	Content
<b>Keywords</b>	LPCXpresso, LPC1100, LPC1200, LPC1300, LPC1700, LPC1800, LPC2000, LPC2900, LPC3000, LPC3100, LPC3200, LPC4300
<b>Abstract</b>	LPCXpresso is a new, low-cost development platform available from NXP. This document is a brief overview on how to get started with LPCXpresso.



**Revision history**

Rev	Date	Description
11	20110614	<ul style="list-style-type: none"><li>• Updates for LPCXpresso 4- new screen shots</li><li>• Added 1.1 V4 new features section</li><li>• Updated comprehensive supported parts list</li><li>• Updated create new project process</li></ul>
10	20110407	<ul style="list-style-type: none"><li>• Added Fig 45 and Fig 46.</li></ul>
9	20110301	<ul style="list-style-type: none"><li>• Updated keywords and supported products throughout</li><li>• Updated Section 6.1</li><li>• Updated Section 6.2.6</li><li>• Updated Section 6.6.2</li><li>• Removed Fig 20</li><li>• Added Fig 42 and Fig 43</li></ul>
8	20110211	<ul style="list-style-type: none"><li>• Updated Section 3.2</li><li>• Added Fig 39, Fig 40, Fig 41, Fig 44</li></ul>
7	20100915	<ul style="list-style-type: none"><li>• Updated Section 3.1</li></ul>
6	20100712	<ul style="list-style-type: none"><li>• Added 7.1 Schematics for LPCXpresso LPC1768 target side</li><li>• Added 6.1 Installing Eclipse plugins</li></ul>
5	20100604	<ul style="list-style-type: none"><li>• Added new products supported to Introduction section: LPC2929, LPC3250</li><li>• Removed 6.1.6 Download performance</li><li>• Updated 6.4.2 Optimization section</li></ul>
4	20100419	<ul style="list-style-type: none"><li>• Updated Fig 47</li></ul>
3	20100315	<ul style="list-style-type: none"><li>• Updated Fig 38</li><li>• Added Fig 39</li></ul>
2	20100311	<ul style="list-style-type: none"><li>• Updated Section 3.1</li><li>• Added Section 6.2.6</li></ul>
1	20100111	<ul style="list-style-type: none"><li>• Initial version</li></ul>

**Contact information**

For additional information, please visit: <http://www.nxp.com>

For sales office addresses, please send an email to: [salesaddresses@nxp.com](mailto:salesaddresses@nxp.com)

## 1. Introduction

LPCXpresso is a new, low-cost development platform available from NXP. The software consists of an enhanced, Eclipse-based IDE, a GNU C compiler, linker, libraries, and an enhanced GDB debugger. The hardware consists of the LPCXpresso development board which has an LPC-Link debug interface and an NXP LPC ARM-based microcontroller target. LPCXpresso is an end-to-end solution enabling embedded engineers to develop their applications from initial evaluation to final production.

The LPCXpresso IDE, powered by Code Red Technologies ([www.code-red-tech.com/lpcxpresso/](http://www.code-red-tech.com/lpcxpresso/)), is based on the popular Eclipse development platform and includes several LPC-specific enhancements. It is an industry-standard GNU toolchain with an optimized C library that gives engineers all the tools necessary to develop high-quality software solutions quickly and cost-effectively. The C programming environment includes professional-level features. There is syntax coloring, source formatting, function folding, on- and offline help, and extensive project management automation.

The LPCXpresso target board, jointly developed by NXP, Code Red Technologies, and Embedded Artists (<http://www.embeddedartists.com/products/lpcxpresso/>), includes an integrated JTAG debugger (LPC-Link), so there's no need for a separate JTAG debug probe. The target portion of the board can connect to expansion boards to provide a greater variety of interfaces, and I/O devices. The on-board LPC-Link debugger provides a high-speed USB to JTAG/SWD interface to the IDE and it can be connected to other debug targets such as a customer prototype. Users can also use the LPCXpresso IDE with the Red Probe JTAG adapter from Code Red Technologies.

Supported LPC products and board part numbers on the LPCXpresso platform:

- **LPC1100:** LPC1102 LPC1111/101 LPC1111/102 LPC1111/201 LPC1111/202  
LPC1112/101 LPC1112/102 LPC1112/201 LPC1112/202 LPC1113/201  
LPC1113/202 LPC1113/301 LPC1113/302 LPC1114/201 LPC1114/202  
LPC1114/301 LPC1114/302 LPC11C12/301 LPC11C14/301 LPC11C22/301  
LPC11C24/301 LPC11U12/201 LPC11U13/201 LPC11U14/201
  - OM11049: LPC1114/302
  - OM13014: LPC11U14
  - OM13012: LPC11C24
- **LPC1200:** LPC1224/201 LPC1224/221 LPC1225/301 LPC1225/321 LPC1226/301  
LPC1227/301
  - OM13008: LPC1227
- **LPC1300:** LPC1311 LPC1311/01 LPC1313 LPC1313/01 LPC1342 LPC1343
  - OM11048: LPC1343
- **LPC1700:** LPC1751 LPC1752 LPC1754 LPC1756 LPC1758 LPC1759 LPC1763  
LPC1764 LPC1765 LPC1766 LPC1767 LPC1768 LPC1769 LPC1774 LPC1776  
LPC1777 LPC1778 LPC1785 LPC1786 LPC1787 LPC1788
  - OM13000: LPC1769
- **LPC1800:** Coming soon
- **LPC2000:** LPC2109 LPC2109/01 LPC2134 LPC2142 LPC2362 LPC2929
- **LPC3000:** LPC3130 LPC3250
- **LPC4000:** Coming soon

LPCXpresso base board products:


- OM11083: Embedded Artists Base Board for LPCXpresso and mbed
- OM13009: Embedded Artists Motor Control Kit for LPCXpresso
- OM13016: NGX mbed-LPCXpresso baseboard

### 1.1 LPCXpresso 4 new features

- Support for CMSIS v2.0 included
- Based on eclipse Helios and gcc 4.5.1
- New part support

For more information on LPCXpresso 4 new features visit:

<http://support.code-red-tech.com/CodeRedWiki/NewInVersion4>



## 1.2 LPCXpresso IDE

LPCXpresso's IDE is a highly integrated software development environment for NXP's LPC Microcontrollers, which includes all the tools necessary to develop high quality software solutions in a timely and cost effective fashion. LPCXpresso is based on Eclipse with many LPC specific enhancements. It also features the latest version of the industry standard GNU tool chain with a proprietary optimized C library providing professional quality tools at low cost. The LPCXpresso IDE can build an executable of any size with full code optimization and it supports a download limit of 128 kB after registration. LPCXpresso supports the full embedded product design cycle by moving beyond chip evaluation boards and supporting development on external target boards.




Fig 1. LPCXpresso IDE

### 1.3 LPCXpresso development board




Fig 2. LPCXpresso development board

### 1.4 LPC-LINK JTAG/SWD debugger

The LPCXpresso board contains a JTAG/SWD debugger called the “LPC-Link” and a target MCU. LPC-Link is equipped with a 10-pin JTAG header (highlighted on the above image) and it seamlessly connects to the target via USB (the USB interface and other debug features are provided by NXP’s ARM9 based LPC3154 MCU). Cutting the tracks between the LPC-link and the target will make the LPC-Link a stand-alone JTAG debugger. This enables the LPCXpresso platform to be connected to an external target and used to develop for a wide variety of NXP’s Cortex-M0, Cortex-M3, and ARM7/9 based applications. Currently supported microcontroller products include LPC1700, LPC1300, LPC1200, and LPC1100 series and specific members of the LPC2000 and LPC3000 families.

### 1.5 Integrated evaluation target

The target includes a small prototyping area and easily accessible connections for expansion. The LPCXpresso board with target can be used

- On its own for software development and benchmarking
- Connected to an off-the-shelf baseboard for rapid proof-of-concepts
- Connected to customer-designed board for a full prototype

### 1.6 LPCXpresso partners

NXP has partnered with Code Red Technologies and Embedded Artists for the LPCXpresso platform. For added flexibility and higher memory configurations, the

LPCXpresso platform can easily be upgraded to include full-blown suites from Code Red Technologies and more advanced hardware kits from Embedded Artists. Please visit the LPCXpresso webpage for more information.



## 2. Evaluate, explore and develop




Fig 3. Product development stages

Users can envisage three stages from evaluation to product development. During evaluation, features and peripherals of the target MCU can be easily tested with the prototyping area and easily accessible connections on the target board. Complementing the target board are also easy-to-use example projects and a handy Getting Started guide. For rapid proof-of-concepts, users can get an off-the-shelf base board from Embedded Artists and quickly explore the next level of applications. And finally LPCXpresso users can seamlessly develop their final application by using the LPC-Link's 10-pin JTAG connector to attach any JTAG-capable custom board. This way, users can now enjoy the same user experience right from evaluation to product development.



### 3. Installation

#### 3.1 System requirements

Operating System	Microsoft® Windows - XP 32-bit (SP2 or greater) Microsoft® Windows - Vista 32-bit or 64-bit Microsoft® Windows - Windows 7 32-bit or 64-bit Linux - Ubuntu 9, 10, and 11 Linux - Fedora 12 and 13
System RAM	512 MB minimum (1 GB recommended)
Hard Disk	300+ MB of available space.
Screen/Display Adaptor	1024x768 minimum recommended
Internet Connection	High-speed internet is recommended to download and register the software

Note: LPCXpresso may install and run on other Linux distributions. However, only the distributions listed above have been tested. Desktop virtualization tools supporting a linux or Windows guest with USB support can be used to run LPCXpresso on other computing platforms.

#### 3.2 Installation process

LPCXpresso is installed into a single directory, of your choice. Multiple versions can be installed simultaneously without any issues. The installation process is to double-click the installer file after downloading. Then click “next” on the setup wizard. To install under linux, the downloaded file should be marked as executable first using `chmod +r`.




Fig 4. Setup wizard




Fig 5. Setup wizard

Read the license agreement then click next. There are a number of other screens on the setup wizard, but generally the default options can be accepted. After the install, an information file will be displayed. Click "Next." Congratulations! Your LPCXpresso installation is complete!




Fig 6. Setup wizard

### 3.3 Activation

To activate your product from LPCXpresso, choose Help->Product activation->Create serial number and register. Once the wizard is open, click “Copy to clipboard” to copy the LPCXpresso serial number into the clipboard. This serial number is based on your machine’s hardware and operating system configuration, but contains no personally identifiable information. Now click the button to open the registration activation page. This should display a web form. After completing the form, you will receive an activation code via email within a few minutes. Highlight the activation code in your email program, and select Copy to place it into the Windows clipboard. Now, choose select Help->Product activation->Enter activation code from within LPCXpresso. Paste the product activation code into the Product activation dialog by right clicking in the Activation code field and choosing “Paste.” Then click the “OK” button. You should receive a dialog confirming acceptance of the activation code. It is also possible to complete LPCXpresso activation on a PC that is offline as long as another PC has access to the Internet. Refer to [Fig 7](#) for the process.




Fig 7. LPCXpresso activation with offline PC

## 4. Getting familiar with the LPCXpresso IDE

LPCXpresso IDE is based on the Eclipse IDE framework and many of the core features are described well in generic Eclipse documentation and in the help files found in the help menu of the product. Further documentation and pointers to useful documents are also available on the Code Red Technologies Wiki at <http://support.code-red-tech.com/CodeRedWiki>.

### 4.1 Layout of the LPCXpresso desktop

LPCXpresso's Desktop contains many windows. Each window is called a View, because it displays a particular view of data in the LPCXpresso environment. This data could be source code, hex dumps, disassembly, memory contents, or more. Views can be opened, moved, docked, and closed, and the layout of the currently displayed Views can be saved and restored. A specific configuration of Views is called a 'Perspective.' Typically, LPCXpresso operates in a single perspective under which both the code development & debug sessions operate as shown on the next page. The single perspective greatly simplifies the Eclipse environment and enhances the entire LPCXpresso experience.

All Views in the Perspective can be moved around by dragging and dropping. If a View is accidentally closed, it can be restored by selecting it from the Show View dialog. The Show View dialog can be opened from the Show View Other... option in the Window menu.





Fig 8. Show view/other menu

### 4.1.1 Single perspective (code development)



**Fig 9. Single perspective (develop)**

1. Project Explorer View: The 'Project Explorer' gives you a view of all the projects in your current 'Workspace'. A 'Workspace' is a collection of projects that are stored in a single Workspace Directory on your computer.
2. Editor: On the upper right is the editor which allows modification and saving of source code as well as setting breakpoints in debug mode.
3. Console and Problems Views: On the lower right are the Console and Problems Views. The Console View displays status information on compiling and debugging, as well as program output. The Problem View (available by changing tabs) shows all compiler errors and will navigate the Editor View to the error location.
4. Quick Start View: Below, the 'Quick Start' view has fast links to commonly used features. This is the best place to go to find options such as Build, Debug, and Import.

## 4.1.2 Single perspective (debug)




Fig 10. Single perspective (debug)

1. Core Register View: This shows all of the registers in the processor core. Registers that have changed from step to step are highlighted in yellow.
2. Debug View: This shows you the stack trace and the debug toolbar. Using the icons at the top of the view, you can step through code or execute at full speed. In the 'stopped' state, you can click on any particular function and inspect its local variables in the right hand panel on the Variables tab.
3. Editor: In here you will see the code you are executing and can step from line to line. By pressing the 'i' icon at the top of the Debug view, you can switch to stepping by assembly instruction. Clicking in the left margin will set and delete breakpoints.
4. Console View: On the lower right is the Console View. The Console View displays status information on compiling and debugging, as well as program output.
5. Quick Start View: Below, the 'Quick Start' view has fast links to commonly used features. This is the best place to go to find options such as Build, Debug, and Import.

4.1.2.1 Peripheral views

LPCXpresso includes full, annotated and interactive debug views of all the peripherals. Access to the views is found on the Peripherals View (click the Peripherals tab) behind the Core Registers view. Each peripheral can be selected, and it is displayed in the 'Memory' view which is located behind the 'Console' view at the bottom of the LPCXpresso desktop.




Fig 11. Display of peripheral view showing selection of ADC peripheral




Fig 12. Display of memory view showing detail of ADC peripheral registers

## 4.2 Connecting the target

To begin development, the LPCXpresso can be connected to a PC using a USB 2.0 A/Mini-B cable.



**Fig 13. USB 2.0 A/Mini-B cable**

If you are debugging a prototype board or a target containing a different MCU, see the Appendix for a pinout to connect the debugger section of the LPCXpresso to an external target.



## 5. Examples: Download, build, download and debug

### 5.1 Downloading NXP sample code from the web




Fig 14. Quickstart panel

First, select “Import project(s)” from the Quickstart panel in the lower left corner of the screen.




Fig 15. Import project(s) dialog

Next, select “Browse for more examples...” from the Import project(s) dialog.






Fig 16. <http://www.nxp.com/lpcxpresso-support> web site

The LPCXpresso-Support web page should appear. It has links to NXP sample code that has been developed for LPCXpresso. Select the sample code that applies to your Target Device and download it. Then, switch back to LPCXpresso and use the Browse button to select the .zip file.



**Fig 17. Zip file from LPCXpresso-Support web site selected for importing**

Now click the Next button and then choose which projects to import from the .zip file.



**Fig 18. Import projects(s):-Selecting which projects to import**

Often, there will be references between projects in a .zip file so it is best to import all of them.




Fig 19. Import projects: Progress indicator

- There is also a local LPCXpresso examples directory. This is often located at C:\nxp\lpcxpresso\lpcxpresso\examples.

## 5.2 Debugging/running 'blinky' or another project on your LPCXpresso board

In LPCXpresso, when you start to debug, your program will automatically download to the target and be programmed into flash memory.

To start debugging on your target, simply highlight the project in the Project Explorer and then in the Quickstart Panel select 'Debug 'Projectname' [Debug]'.






Fig 20. Debug

You may also enter debug mode by clicking the bug icon on the top LPCXpresso toolbar.









**Fig 21. Bug icon**

You are then presented with the debug view and toolbar and have run control over the code running on your target. The debug toolbar will pop up above the code window.



**Fig 22. Debug toolbar**

You can now do the following with the buttons towards the top of the 'Debug' view:

	Run the program.
	Step Over C/C++ line.
	Step into a function.
	Stop the debugger.
	Pause Execution of the running program.
	Instruction stepping mode (disassembly)

**Fig 23. Debug buttons**

## 6. LPCXpresso IDE tips and tricks

### 6.1 Installing Eclipse plugins

The LPCXpresso IDE contains many of the features of the Eclipse open-source IDE from <http://www.eclipse.org>. The browse and install plugin function is present in the help menu. To access it, choose Help -> Install New Software. This will display the Eclipse Install Software dialog which will allow browsing and installing of Eclipse plugins.

### 6.2 Debugging tips

#### 6.2.1 Debug features not enabled

All of the LPCXpresso features are context-sensitive. If features are disabled, double-check that you are navigated into a .c file in an open project on the Project Explorer View, or some menu items and toolbar buttons may be disabled. If your workspace contains projects that create libraries such as CMSIS, please note that debug features will be disabled if you are currently editing a .c file that is part of a library project.

#### 6.2.2 Error launching Debug\filename.axf




Fig 24. Error starting debug

LPCXpresso checks the target chip ID against the currently selected chip ID for the project and will not start if there is not a match. Make sure that the correct NXP LPC microcontroller part is selected in LPCXpresso. The current part number is displayed in the status bar at the bottom of the LPCXpresso window. It can be changed by holding down the Ctrl key and clicking. A dialog will appear allowing selection of the correct part number.




Fig 25. Current part number




Fig 26. Selecting correct part number

### 6.2.3 Optimization issues

When optimization is enabled, it will reorder code. What this means is that the code from multiple C lines will be intermingled. In addition, assignments and initializations might be pulled out of loops so they are only executed once. Changes like these will make the code confusing to debug. Some symptoms you might see are breakpoints that only work the first time through, or seeing the debugger's current line indicator fail to advance or even move backwards when you click step. It is best to always use `-O0` for debugging. Since optimization can make such a big difference in code size and performance, it is a good idea to test your project with optimization and plan for a final build that is optimized.

### 6.2.4 Displaying assembly instructions

Click the `i->` icon. This changes the Instruction Stepping Mode to step by processor instructions, rather than source lines. This also shows the disassembly view around the current instruction.

### 6.2.5 Exiting debug mode and stopping debugging

To stop debug press the 'Stop' button (red square) shown in the toolbar at the top of the debug view.

### 6.2.6 Recovery of board

After playing around with the LPCXpresso board, especially when trying out new PLL settings, reconfiguring the SWDIO/SWDCLK pin functions, disabling AHBCLKCTRL bits, or trying power down modes, the board may be disabled and no longer enter debug mode. This is caused by code on the on-board flash that incorrectly disables the system clocks or the debug port soon after reset before the debugger can connect to the core. The easiest solution to this is to load a working project into LPCXpresso, ground the ISP pin (see the chip User's Manual for details) and then try to enter debug mode.

Grounding the ISP pin during reset will put the target MCU into In-System Programming (ISP) mode. It will wait for a command through the serial port or the USB port. This



temporarily prevents the troublesome code in flash from starting. Although ISP is designed to enable serial and USB updates, while ISP is running, the LPCXpresso toolchain is able to connect to the Cortex core and reprogram the flash. After the flash is reprogrammed, disconnect the ISP pin (pull it high or allow it to float) and stop debugging. Now you should be able to debug code again.

### 6.3 Datasheet browser

The LPCXpresso IDE comes with an integrated web browser that will direct viewers to the datasheet of the device. Just click on the part number in the lower right border of the LPCXpresso window to see the browser in action.




Fig 27. Integrated web browser

### 6.4 Code size

#### 6.4.1 printf

When optimizing a project for size, if you are using printf, make sure that Redlib is selected as the standard library in the Projects Properties dialog. This option can be set using the Quick Settings dropdown box in the Quick Start panel.




Fig 28. Reconfigure library setting

The printf implementation in Redlib is about half the size of the implementation in Newlib. A smaller printf library can be used in Redlib if floating point formatting strings are not used. To select this smaller library, define the symbol CR\_INTEGER\_PRINTF to the compiler (i.e. -DCR\_INTEGER\_PRINTF). To save even more space, avoid using printf or any C standard library functions and select Redlib (none). Depending on your printf settings and code, this could free up 10K to 20K of flash memory.

### 6.4.2 Optimization

Optimization can do a lot to save flash memory. It can be configured in the same dialog as the C standard library. Choose “Optimization” under “MCU C Compiler” in the “Tool Settings” tab. Higher levels of optimization will typically result in higher performance, but may result in larger code size. It is best to use -O0 for debugging and higher levels for Release. For best code size try -Os -mword-relocations. To further reduce code, add --gc-sections to the project linker flags. This causes the linker to remove unused functions from the compiled code. --gc-sections is enabled by default in new projects created by the project wizard. If you are working with an existing project, you may need to manually add this option to your project. --gc-sections is safe to use in both Release and Debug builds. There are many optimization options available for GCC. Visit <http://gcc.gnu.org/onlinedocs/gcc/Optimize-Options.html> to see all of them.

## 6.5 Showing hidden views

A view is an on-screen representation of something in the IDE. A view can be source code, the project tree, or a debug window. If you accidentally close a view, you can open it again by going to the Window menu and choosing Show View and Other. It is a good idea to browse through the Show View window to see what is available.




Fig 29. Show view window

This will present a dialog allowing you to pick a view and display it.

## 6.6 Creating a 'skeleton' project in a new Workspace

LPCXpresso includes several project Templates to help get started quickly.

### 6.6.1 Create a new Workspace

From the 'File' menu hover over 'Switch Workspace' and then select 'Other...' from the bottom of the list. You will then see the 'Workspace Launcher' dialog shown below.

Enter or browse to the new path for your workspace. We have called our new workspace 'NewWorkspace'.





Fig 30. Workspace launcher

Then click on OK to re-open LPCXpresso with this new workspace selected.


### 6.6.2 Create the 'Skeleton' project

- If you are using a Cortex-based part, first, import the CMSIS header files for the chip family you are planning to work with. To do this, click "Import Project" and navigate to the CMSIS<version/part>.zip. The CMSIS header files are installed with LPCXpresso in C:\nxp\lpcxpresso\lpcxpresso\examples\nxp. Once this project is added to your workspace, click "Build all projects (Debug)" in the Quickstart Panel.
- Click on 'New project...' and select the NXP C project type for your architecture.
- Click "Next" and enter a project name. In this case we will use 'MyProject' then click 'Next.'



**Fig 31. Enter project name**

- The next section of the dialog will ask you to specify which chip in the family you are using.



**Fig 32. Enter project name**

-

- If you are using a Cortex-based part, the next step in the wizard will ask which CMSIS project to use. CMSIS stands for Cortex Microcontroller Software Interface Standard. CMSIS defines a common way to access peripheral registers and to define interrupts. Please select the project that you imported into the workspace earlier and click Finish.




Fig 33. CMSIS selection

Congratulations! You have created your first project!




Fig 34. Project creation complete

## 7. Appendix

---

### 7.1 LPCXpresso target side schematics




Fig 35. Schematic for the LPCXpresso LPC1769 target side (1 of 3)






Fig 36. Schematic for the LPCXpresso LPC1769 target side (2 of 3)

**Embedded Artists**

(C) Embedded Artists AB

TITLE: LPCXpresso LPC1769 rev B

Document Number:

Date: 2010-10-19 14:19:36 Sheet: 6/7




Fig 37. Schematic for the LPCXpresso LPC1769 target side (3 of 3)

**Embedded Artists**

(C) Embedded Artists AB

TITLE: LPCXpresso LPC1769 rev B

Document Number:

Date: 2010-10-19 14:19:36 Sheet: 7/7




Fig 38. Schematic for the LPCXpresso LPC1114 target side<sup>1</sup>

1. Design and layout compatible with LPC1343 version. Therefore, PIO2\_4/5 and PIO3\_4/5 swap. LPC1114 does not have USB, but LPC1343 does. Therefore R37/38. LPC1114 does not have SWO, but PIO0\_9 is connected (since LPC1343 has SWO there).




Fig 39. Schematic for the LPCXpresso LPC1343 target side




Fig 40. Schematic for the LPCXpresso LPC11C24 target side, part 1




Fig 41. Schematic for the LPCXpresso LPC11C24 target side, part 2






Fig 42. Schematic for the LPCXpresso LPC1200 target side, part 1

**NXP Semiconductors**

TITLE: LPCXpresso LPC1200 rev B

Document Number: REU:

Date: not saved! Sheet: 5/6




Fig 43. Schematic for the LPCXpresso LPC1200 target side, part 2






Fig 44. Dimensioned drawing of LPCXpresso LPC1227, LPC1343, LPC1114/301, LPC1114/302, LPC11C24, LPC1769, LPC1768





Fig 45. Schematic for the LPCXpresso LPC11U14 target side, part 1



**Embedded Artists**

(C) Embedded Artists AB

TITLE: LPCXpresso LPC11U14 rev A

Document Number: \_\_\_\_\_ REV: \_\_\_\_\_

Date: 2/17/2011 8:34:11 PM      Sheet: 6/6

Fig 46. Schematic for the LPCXpresso LPC11U14 target side, part 2

### 7.2 LPCXpresso PCB pinout and dimensions

The schematics of the LPCXpresso Target and the LPC-LINK debug connector appear in [Fig 35](#) to [Fig 46](#). The LPCXpresso board was designed to be pin compatible with NXP mbed. LPCXpresso can be powered either through the debug mini-USB port, by 3.3 V applied to the board, or by 5 V applied to the USB connector. A cable for the 10-pin mini JTAG connector on the LPC-LINK debugger portion of LPCXpresso can be purchased from Digi-Key, part number FFSD-05-D-06.00-01-N.

Dimensions: A dimensioned drawing of LPCXpresso can be found in [Fig 44](#). LPCXpresso LPC1343's outer dimensions are 1.35x5.45 inches. It contains two rows of holes 900 mil apart. Each row has 27 connections and holes are drilled at a 100 mil pitch.




Fig 47. LPCXpresso LPC-LINK JTAG/SWO pinout

### 7.3 Enabling USB connectivity “to LPC1343 target”

The LPCXpresso board is simple yet flexible. Here is a way to configure it to support the development of USB devices using the LPC1343 or other USB-capable NXP microcontroller. The LPC1343 has a USB phy on-chip. To connect the microcontroller to a USB port, it is only necessary to add a USB connector and a pullup resistor.

Note: This simple connection does not implement NXP Soft-Connect to allow soft disconnection and connection to the USB bus. Because of this, the USB connection must be plugged into the PC near the time the USB peripheral is initialized, or after. If the USB port is connected when the LPC USB peripheral is not initialized, the pullup resistor will notify the PC that a USB device is present, yet the microcontroller will not respond because it has not been initialized. This will trigger windows to generate an error regarding a malfunctioning USB device. Unplug and re-plug the device to dismiss the error.

Note 2: Rather than building a cable or wiring a USB Type-A connector, you could take an existing A-B USB cable and cut off the B connector. Then the A side of the cable could be stripped and soldered onto the LPCXpresso board.




Fig 48. USB retrofit schematic




Fig 49. LPC1343 target connected to Type-A USB cable

## 7.4 Terminology

### LPCXpresso

The Code Red Technologies IDE (Integrated Development Environment) based on Eclipse with our own extensions for embedded development.

### SWD

Serial Wire Debugging (Single Wire Debugging). This is a debug connection technology available on the Cortex-M3 that allows debug through just 2-wires unlike 5 for JTAG.

### ELF (Executable and Linking Format)

This is the object code file format used by our development tool chain and most microprocessor tool chains.

### Workspace

LPCXpresso organizes groups of projects into a 'Workspace'. A workspace is stored as a directory on your host PC and has subdirectories containing individual projects.

### Project

An LPCXpresso project. A project contains all of the .c and .h files to build a single microcontroller flash image.

### Perspective

In LPCXpresso, a perspective is a particular collection of 'Views' that are grouped together to be suitable for a particular use. For example the 'C/C++ programming' perspective and the 'Debug' perspective.

### View

A 'View' is a window in LPCXpresso that shows a particular file or activity. A view could be of a C source code file or something live such as a disassembly window or register dump. A 'Perspective' is the layout of many 'Views'.

### Semi-hosting

The ability to use IO on your debugger host system for your target embedded system. For example a 'printf' will appear in the console window of the debugger.

### Debug Target

The system being debugged. LPCXpresso includes a target microcontroller on-board, but can also be connected to external targets.

### Redlib™

The optimized Code Red Technologies C runtime library (non-GNU). LPCXpresso includes both Redlib and Newlib libraries.

## References

- [1] NXP LPCXpresso <http://www.nxp.com/lpcxpresso>
- [2] NXP LPCZone <http://www.nxp.com/lpczone>
- [3] NXP Microcontrollers <http://www.nxp.com/microcontrollers>
- [4] Code Red Technologies Wiki <http://lpcxpresso.code-red-tech.com/LPCXpresso/softwareknowledgebase>
- [5] Code Red Technologies LPCXpresso page <http://www.code-red-tech.com/lpcxpresso>
- [6] Embedded Artists AB <http://www.embeddedartists.com>
- [7] Harbison, S.P. & Steele, G.L. (2002). *C: A Reference Manual (5<sup>th</sup> Edition)*. Prentice Hall.
- [8] Yiu, J. (2007). *The Definitive Guide to the ARM Cortex-M3*. Oxford, UK: Newnes.
- [9] Yiu, J. (2011). *The Definitive Guide to the ARM Cortex-M0*. Oxford, UK: Newnes.
- [10] ARM Cortex-M3 Technical Reference Manual. Revision: r2p0. (ARM DDI 0337G). <http://infocenter.arm.com/help/index.jsp>
- [11] ARM Cortex-M0 Technical Reference Manual. Revision: r1p0. (ARM DDI 0413D). <http://infocenter.arm.com/help/index.jsp>
- [12] ARMv7-M Architecture Reference Manual (ARM DDI 0403) <http://infocenter.arm.com/help/index.jsp>
- [13] ARMv6-M Architecture Reference Manual (Cortex-M0/LPC11) <http://infocenter.arm.com/help/index.jsp>

## 8. Legal information

### 8.1 Definitions

**Draft** — The document is a draft version only. The content is still under internal review and subject to formal approval, which may result in modifications or additions. NXP Semiconductors does not give any representations or warranties as to the accuracy or completeness of information included herein and shall have no liability for the consequences of use of such information.

### 8.2 Disclaimers

**Limited warranty and liability** — Information in this document is believed to be accurate and reliable. However, NXP Semiconductors does not give any representations or warranties, expressed or implied, as to the accuracy or completeness of such information and shall have no liability for the consequences of use of such information.

In no event shall NXP Semiconductors be liable for any indirect, incidental, punitive, special or consequential damages (including - without limitation - lost profits, lost savings, business interruption, costs related to the removal or replacement of any products or rework charges) whether or not such damages are based on tort (including negligence), warranty, breach of contract or any other legal theory.

Notwithstanding any damages that customer might incur for any reason whatsoever, NXP Semiconductors' aggregate and cumulative liability towards customer for the products described herein shall be limited in accordance with the Terms and conditions of commercial sale of NXP Semiconductors.

**Right to make changes** — NXP Semiconductors reserves the right to make changes to information published in this document, including without limitation specifications and product descriptions, at any time and without notice. This document supersedes and replaces all information supplied prior to the publication hereof.

**Suitability for use** — NXP Semiconductors products are not designed, authorized or warranted to be suitable for use in life support, life-critical or safety-critical systems or equipment, nor in applications where failure or malfunction of an NXP Semiconductors product can reasonably be expected to result in personal injury, death or severe property or environmental damage. NXP Semiconductors accepts no liability for inclusion and/or use of

NXP Semiconductors products in such equipment or applications and therefore such inclusion and/or use is at the customer's own risk.

**Applications** — Applications that are described herein for any of these products are for illustrative purposes only. NXP Semiconductors makes no representation or warranty that such applications will be suitable for the specified use without further testing or modification.

Customers are responsible for the design and operation of their applications and products using NXP Semiconductors products, and NXP Semiconductors accepts no liability for any assistance with applications or customer product design. It is customer's sole responsibility to determine whether the NXP Semiconductors product is suitable and fit for the customer's applications and products planned, as well as for the planned application and use of customer's third party customer(s). Customers should provide appropriate design and operating safeguards to minimize the risks associated with their applications and products.

NXP Semiconductors does not accept any liability related to any default, damage, costs or problem which is based on any weakness or default in the customer's applications or products, or the application or use by customer's third party customer(s). Customer is responsible for doing all necessary testing for the customer's applications and products using NXP Semiconductors products in order to avoid a default of the applications and the products or of the application or use by customer's third party customer(s). NXP does not accept any liability in this respect.

**Export control** — This document as well as the item(s) described herein may be subject to export control regulations. Export might require a prior authorization from national authorities.

### 8.3 Trademarks

Notice: All referenced brands, product names, service names and trademarks are property of their respective owners.



## 9. Contents

<b>1.</b>	<b>Introduction .....</b>	<b>3</b>		
1.1	LPCXpresso 4 new features.....	4	7.4	Terminology.....
1.2	LPCXpresso IDE .....	5	References.....	47
1.3	LPCXpresso development board .....	6	<b>8.</b>	<b>Legal information .....</b>
1.4	LPC-LINK JTAG/SWD debugger .....	6	8.1	Definitions.....
1.5	Integrated evaluation target.....	6	8.2	Disclaimers.....
1.6	LPCXpresso partners.....	6	8.3	Trademarks .....
<b>2.</b>	<b>Evaluate, explore and develop .....</b>	<b>8</b>	<b>9.</b>	<b>Contents .....</b>
<b>3.</b>	<b>Installation .....</b>	<b>9</b>		
3.1	System requirements .....	9		
3.2	Installation process .....	9		
3.3	Activation.....	11		
<b>4.</b>	<b>Getting familiar with the LPCXpresso IDE .....</b>	<b>12</b>		
4.1	Layout of the LPCXpresso desktop .....	12		
4.1.1	Single perspective (code development) .....	13		
4.1.2	Single perspective (debug).....	14		
4.1.2.1	Peripheral views.....	15		
4.2	Connecting the target.....	16		
<b>5.</b>	<b>Examples: Download, build, download and debug .....</b>	<b>17</b>		
5.1	Downloading NXP sample code from the web .	17		
5.2	Debugging/running 'blinky' or another project on your LPCXpresso board.....	20		
<b>6.</b>	<b>LPCXpresso IDE tips and tricks .....</b>	<b>23</b>		
6.1	Installing Eclipse plugins .....	23		
6.2	Debugging tips .....	23		
6.2.1	Debug features not enabled .....	23		
6.2.2	Error launching Debugfilename.axf .....	23		
6.2.3	Optimization issues .....	24		
6.2.4	Displaying assembly instructions .....	24		
6.2.5	Exiting debug mode and stopping debugging ..	24		
6.2.6	Recovery of board.....	24		
6.3	Datasheet browser .....	25		
6.4	Code size .....	25		
6.4.1	printf .....	25		
6.4.2	Optimization .....	26		
6.5	Showing hidden views.....	26		
6.6	Creating a 'skeleton' project in a new Workspace .....	27		
6.6.1	Create a new Workspace.....	27		
6.6.2	Create the 'Skeleton' project .....	27		
<b>7.</b>	<b>Appendix .....</b>	<b>31</b>		
7.1	LPCXpresso target side schematics .....	31		
7.2	LPCXpresso PCB pinout and dimensions .....	44		
7.3	Enabling USB connectivity "to LPC1343 target"			

---

Please be aware that important notices concerning this document and the product(s) described herein, have been included in the section 'Legal information'.

---