

Dimensions (mm)			
Range (length "A")	200 to 1000	1001 to 5000	5001 to 20000
Tolerance (mm)	± 10	± 15	± 20


1) "B" = "A" - 52mm

Alignment of housings in any order. e

**Interface**

According to

RN 059-01



Dieses Dokument ist urheberrechtlich geschützt • This document is protected by copyright • Rosenberger Hochfrequenztechnik GmbH & Co. KG

RF\_35/09.14/6.2

**Change history**

Rev.	Date	Change
d00	08.10.13	Changed the table for the range (length) A and the tolerance
e00	19.04.16	Added note " Alignment of housings in any order."
f00	26.04.16	Length '(“B”)' with note '1)' added Note '1) “B” = “A” – 52mm' added From 'length A & C' to 'length “A”'

While the information has been carefully compiled to the best of our knowledge, nothing is intended as representation or warranty on our part and no statement herein shall be construed as recommendation to infringe existing patents. In the effort to improve our products, we reserve the right to make changes judged to be necessary.

Draft	Date	Approved	Date	Rev.	Engineering change number	Name	Date
M. Ruf	02.03.10	F. Mayer	26.04.16	f00	16-0649	M. Kolbe	26.04.16