

HAMAMATSU

PRELIMINARY DATA
OCT. 2001


POSITION SENSITIVE PHOTOMULTIPLIER TUBES R8520-00-C12 R8520U-00-C12

FEATURES

- 6 (X) + 6 (Y) Cross Plate Anode
- Flangeless Type
- High Speed Response

APPLICATIONS

- PET (Positron Emission Tomography)
- Compact Gamma Camera
- Scintillation Mammography



GENERAL

Parameter		Description	Unit
Spectral Response		300 to 650	nm
Wavelength of Maximum Response		420	nm
Photocathode	Material	Bialkali	—
	Minimum Effective Area	22 × 22	mm ²
Window Material		Borosilicate glass	—
Dynode	Structure	Metal channel dynode	—
	Number of Stages	11	—
Anode		6 (X) + 6 (Y) Cross plate anode	—
Weight		Approx. 28	g
Suitable Socket		E678-32B (sold separately)	—

MAXIMUM RATINGS (Absolute Maximum Values)

Parameter		Value	Unit
Supply Voltage	Between Anode and Cathode	1000	V dc
Average Anode Current in Total		0.1	mA

CHARACTERISTICS (at 25 °C)

Parameter		Min.	Typ.	Max.	Unit
Cathode Sensitivity	Luminous (2856 K)	50	70	—	μA/lm
	Blue Sensitivity Index (CS 5-58)	7	8.5	—	—
Anode Sensitivity	Luminous (2856 K)	15	70	—	A/lm
Gain		—	1 × 10 ⁶	—	—
Anode Dark Current in Total of Anodes (after 30 min storage in darkness)		—	2	10	nA
Time Response	Anode Pulse Rise Time	—	1.4	—	ns

NOTE: Anode characteristics are measured with the voltage distribution ratio shown below.

VOLTAGE DISTRIBUTION RATIO AND SUPPLY VOLTAGE

Electrodes	K	G	Dy1	Dy2	Dy3	Dy4	Dy5	Dy6	Dy7	Dy8	Dy9	Dy10	Dy11	P
Ratio	0.5	1.5	2	1	1	1	1	1	1	1	1	1	1	0.5

Supply Voltage: 800 V dc, K: Cathode, G: Grid, Dy: Dynode, P: Anode

Subject to local technical requirements and regulations, availability of products included in this promotional material may vary. Please consult with our sales office. Information furnished by HAMAMATSU is believed to be reliable. However, no responsibility is assumed for possible inaccuracies or omissions. Specifications are subject to change without notice. No patent rights are granted to any of the circuits described herein. ©2001 Hamamatsu Photonics K.K.

POSITION SENSITIVE PHOTOMULTIPLIER TUBES R8520-00-C12, R8520U-00-C12

Figure 1: Typical Spectral Response




Figure 2: Typical Gain and Anode Dark Current






Figure 3: Pulse Height Distribution





SUPPLY VOLTAGE : -800 V
 CRYSTAL : 1" CUBE NaI (TI)
 SOURCE : ^{57}Co (122 keV)
 P.H.R. : 16.9 %

Figure 4: Position Response Using PX-anodes





SUPPLY VOLTAGE : -800 V
 LIGHT SOURCE : 2 mm x 2 mm x 20 mm BGO CRYSTAL
 (irradiated by ^{137}Cs)
 A STEP OF SCANNING : 0.5 mm

Figure 5: Spatial Resolution




* Output of each anode under a light spot scanning at a center.

Figure 6: Circuit Diagram Example and Positioning Histogram




Positioning histogram of a 10 × 10 array of 2.0 mm × 2.0 mm × 20 mm GSO elements for 511 keV γ -rays. (crystal pitch is 2.2 mm)

Figure 7: R8520-00-C12 Dimensional Outline and Basing Diagram (Unit: mm)



TPMHA0483EA


Figure 8: R8520U-00-C12 Dimensional Outline and Basing Diagram (Unit: mm)
 (R8520-00-C12 with an Insulation Cover)



TPMHA0484EA


[ACCESSORIES] (Unit: mm)

● Socket E678-32B **SOLD SEPARATELY**



TACCA0094ED

● D Type Socket Assembly E7514 **SOLD SEPARATELY**



TACCA0236EB

POSITION SENSITIVE PHOTOMULTIPLIER TUBES R8520-00-C12, R8520U-00-C12

 **WARNING** ~High Voltage~

The product is operated at high voltage potential. Further, the metal housing of the product is connected to the photocathode (potential) so that it becomes a high voltage potential when the product is operated at a negative high voltage (anode grounded).

Accordingly, extreme safety care must be taken for the electrical shock hazard to the operator or the damage to the other instruments.

* PATENT: USA Pat. No. 5410211 PATENT PENDING: JAPAN 12, USA 8, EUROPE 9

HAMAMATSU

HOME PAGE URL <http://www.hamamatsu.com>

HAMAMATSU PHOTONICS K.K., Electron Tube Center

314-5, Shimokanzo, Toyooka-village, Iwata-gun, Shizuoka-ken, 438-0193, Japan, Telephone: (81)539/62-5248, Fax: (81)539/62-2205

U.S.A.: Hamamatsu Corporation: 360 Foothill Road, P. O. Box 6910, Bridgewater. N.J. 08807-0910, U.S.A., Telephone: (1)908-231-0960, Fax: (1)908-231-1218 E-mail: usa@hamamatsu.com

Germany: Hamamatsu Photonics Deutschland GmbH: Arzbergerstr. 10, D-82211 Herrsching am Ammersee, Germany, Telephone: (49)8152-375-0, Fax: (49)8152-2658 E-mail: info@hamamatsu.de

France: Hamamatsu Photonics France S.A.R.L.: 8, Rue du Saule Trapu, Parc du Moulin de Massy, 91882 Massy Cedex, France, Telephone: (33)1 69 53 71 00, Fax: (33)1 69 53 71 10 E-mail: infos@hamamatsu.fr

United Kingdom: Hamamatsu Photonics UK Limited: 2 Howard Court, 10 Tewin Road Welwyn Garden City Hertfordshire AL7 1BW, United Kingdom, Telephone: 44-(0)1707-294888, Fax: 44(0)1707-325777 E-mail: info@hamamatsu.co.uk

North Europe: Hamamatsu Photonics Norden AB: Smidesvägen 12, SE-171-41 SOLNA, Sweden, Telephone: (46)8-509-031-00, Fax: (46)8-509-031-01 E-mail: info@hamamatsu.se

Italy: Hamamatsu Photonics Italia: S.R.L.: Strada della Moia, 1/E, 20020 Arese, (Milano), Italy, Telephone: (39)02-935 81 733, Fax: (39)02-935 81 741 E-mail: info@hamamatsu.it

TPMH1276E01
OCT. 2001 IP
Printed in Japan (1000)