

Interfacing the X84129 MPS EEPROM to the Motorola 68HC11 Microcontroller

by Applications Staff

This application note demonstrates how the Xicor X84129 MPS EEPROM can be interfaced to the 68HC11 microcontroller family when connected as shown in Figure 1. The interface uses the time-multiplexed address/data bus and two control lines of the 68HC11 to interface to the MPS EEPROM. Although

the X84129 requires minimal glue logic, 3-NAND gates when connected to the 68HC11, the advantage of the MPS EEPROM as a port-less serial memory device is still preserved. The 68HC11 assembly code listing for this application note can be obtained from the web site at <http://www.xicor.com>.




Figure 1. Typical hardware connection for interfacing an X84641/129 to the 68HC11 microcontroller.



Application Note

```

*****
**
** DESCRIPTION:
**
** This file contains general utility routines written in 68HC11 assembly
** language used to interface the 68HC11 to the XICOR X84161/641/129 MPS E2PROM.
** The interface uses the 68HC11 parallel bus and two control lines to connect
** to the X84161/641/129 . The microcontroller R/W and E control lines are connected
** through 3 NAND gates to match the X84161/641/129's /OE and /WE control lines.
** Address lines A15, A14, A13 are decoded for the chip select; mapping the
** X84161/641/129 to address space 6000 - 7FFF.
** The following table lists all the subroutines in this file with a brief
** description:
**
**      ResetD: Resets the device before a read or write can take place
**      Page_Write: Writes a page of data to the device
**      Page_Read: Reads a page of data from the device into the uc's RAM
**      Byte_Read: Reads a byte of data from the device into the uc's RAM
**      Byte_Write: Writes a byte of data to the device
**      Inbyte: Called by read subroutines to shift data in
**      Outbyte: Called by write subroutines to shift data out
**      Sndaddr: Called by read/write subroutines to send address to device
**      SNVWrte: Provides start non-volatile write sequence required for all writes
**      CheckNVW: Checks to makes sure the non-volatile write is completed
**
** The Main program writes a test string into the MPS E2PROM. After
** page is programmed, the first byte of the page is altered. The page is
** then read back and written to a different location in memory.
** The data read is temporarily stored in the internal RAM.
**

```

```
*****
```

```

*****
*
* INTERNAL RAM
*
*****

```

```

RAMBASE      EQU      $0000      THE INTERNAL RAM BASE ADDRESS(Default)
RAMBuff      EQU      RAMBASE    RAM BUFFER ADDRESS
STACK        EQU      RAMBASE+$FF

```

```

*****
*
* PROGRAM CONSTANTS
*
*****

```

```

Address      EQU      $6000
MPSaddress   EQU      $0000
MPSaddress2  EQU      $0100
Page_Size    EQU      32

```

```

*****
*
* RESET VECTOR ENTRY POINT
*
*****

```

```

ORG          $FFFE          RESET VECTOR ADDRESS TO PROGRAM ENTRY

```




Application Note

```

        jsr      Sndaddr      * Send Page address to device
        ldy      #Page_Size  * Y register contains number of bytes/page
PagePW:  ldaa     0,x          * Load the "test string" in the X register
        pshy
        jsr      OutByte     * Sends out the byte in the accum
        puly
        inx              * Increments the X register
        dey              * Decrements the page counter
        bne      PagePW     * Branches until all bytes are written
        jsr      SNVWrte    * Start Nonvolatile Write
        jsr      CheckNVW   * Checks completion of non-volatile write
        rts

```

```

*** Name: Page_Read
*** Description:
*** Function: Reads a page of data from the first address.
*** Calls: Sndaddr, InByte
*** Input:
*** Output:
*** Register Usage: x, y

```

```

Page_Read:
        jsr      Sndaddr      * Send Page address to device
        ldy      #Page_Size  * Y register contains number of bytes/page
        ldx      #RAMBuff    * Sets the index register x to 0
PagePR:  pshy
        jsr      InByte      * Receives the byte of data
        puly
        staa    0,x          * Stores the byte to RAM
        inx              * Increments the X register
        dey              * Decrements the page counter
        bne      PagePR     * Branches until all bytes are read
        rts

```

```

*** Name: Byte_Read
*** Description:
*** Function: Reads a byte of data from the first address.
*** Calls: Sndaddr, InByte
*** Input:
*** Output:
*** Register Usage: x

```

```

Byte_Read:
        jsr      Sndaddr      * Send Byte address to device
        ldx      #RAMBuff    * Sets the index register x to 0
PageBR:  jsr      InByte      * Receives the byte of data
        staa    0,x          * Stores the byte to RAM
        rts

```

```

*** Name: InByte
*** Description: Reads in 8 bits
*** Function:
*** Calls:

```



Application Note

AN 103

```
*** Input:
*** Output:
*** Register Usage:  y
*****
InByte:   ld  y    #$8          * Sets y to 8
          clra                * Clears accum
out2:    ldab   Address       * Load bit from device to accum b
          andb   #00000001b   * Mask-out unwanted bits accum b
          rola                * Rotate accum 1 bit to the left
          aba                    * Mask accum b into accum a
          dey
          bne    out2         * Branch until accum a contains complete byte
          rts
```

```
*****
*** Name: Byte_Write
*** Description:
*** Function: Writes a byte of data to the first address.
*** Calls: Sndaddr, OutByte
*** Input:
*** Output:
*** Register Usage:
*****
Byte_Write:
          jsr    Sndaddr       * Send Byte address to device
          ldaa  #$58          * Load accum with "X"
          jsr    OutByte      * Send
          jsr    SNVWrite     * Start Nonvolatile Write
          jsr    CheckNVW    * Checks completion of non-volatile write
          rts
```

```
*****
*** Name: Sndaddr
*** Description: Send address to the device
*** Function: Writes the 16 bit address to the device.
*** Calls: ResetD, Outbyte
*** Input:
*** Output:
*** Register Usage: y
*****
```

```
Sndaddr:
          jsr    ResetD      * Send the reset signal
          xgdy                * Load the address in Y to double accum
          jsr    OutByte     * send MSB of address
          tba                    * transfer LSB to accum A
          jsr    OutByte     * send LSM of address
          rts
```

```
*****
*** Name: OutByte
*** Description:
```



Application Note

AN 103

```
*** Function: Sends out 8 bits to Address.
*** Calls:
*** Input:
*** Output:
*** Register Usage:  y
*****
OutByte:  ldy      #$8
          rola
out1:     rola
          staa     Address
          dey
          bne      out1
          rts

*****
*** Name: SNVWrte
*** Description:
*** Function: Sends out 8 bits to Address.
*** Calls:
*** Input:
*** Output:
*** Register Usage:
*****
SNVWrte:  ldaa     Address      * sends read command
          ldaa     #$1         * set accum to "1"
          staa     Address      * send write "1" command
          ldaa     Address      * sends read command
          rts

*****
*** Name: CheckNVW
*** Description:
*** Function:
*** Calls:
*** Input:
*** Output:
*** Register Usage:
*****
CheckNVW:  ldaa     Address`    * sends read command
          rora     * rotate D0 to the carry bit
          bcc     CheckNVW      * loop if nonvolatile write is occuring
          rts

TestString: FCC      'xICORMPSXICORMPSXICORMPSXICORMPS'

*****
*** END OF X84161/641/129 MPS INTERTERFACE SOURCE CODE
*****

END
```