



**Contents**

Device	Part number	Quantity	Calibration Option <sup>a</sup>
Open circuit plug	119S12L-000D3	1	FC
Open circuit jack	119K12L-000D3	1	FC
Short circuit plug	119S12S-000D3	1	FC
Short circuit jack	119K12S-000D3	1	FC
Calibration load plug	119S150-C10D3	1	FC
Calibration load jack	119K150-C10D3	1	FC
Calibration adaptor plug/plug	119S101-S20D3	1	FC
Calibration adaptor jack/jack	119K101-K20D3	1	FC
Calibration adaptor plug/jack	119S101-K20D3	1	FC
Calibration adaptor RPC-2.92 plug to SMP plug	03S119-S20S3	1	FC
Calibration adaptor RPC-2.92 jack to SMP jack	03K119-K20S3	1	FC

a. See "Declaration of calibration options" for explanation.

Dieses Dokument ist urheberrechtlich geschützt • This document is protected by copyright • Rosenberger Hochfrequenztechnik GmbH & Co. KG

RF\_35/05;10/6;1

**Documentation**

This kit is delivered with

- **USB-Stick**  
Standard Definitions as data files for Vector Network Analyzer Families PNA (Keysight/Agilent) and ZVA (Rohde&Schwarz). Calibration Certificate as PDF-file.
- **Standard Definitions Cards**  
Printed Standard Definitions that can be used on nearly all Vector Network Analyzers.
- **Kit Info Card**  
Handling precautions and information for installing Standard Definitions on a Vector Network Analyzer.
- **Calibration Certificate**  
Details see "Declaration of calibration options"
- **Operating Manual**

**Electrical specifications**

This specification covers electrical key specifications for the calibration standards of the calibration kit. Specific and more detailed datasheets are available for each kit device among the part number.

Calibration standard	Frequency	Parameter	Specification
<b>Opens<sup>b</sup></b> (plug and jack)	DC to ≤ 4 GHz > 4 to ≤ 10 GHz	Error from Nominal Phase	≤ 2.0° ≤ 4.0°
<b>Shorts<sup>b</sup></b> (plug and jack)	DC to ≤ 4 GHz > 4 to ≤ 10 GHz	Error from Nominal Phase	≤ 2.0° ≤ 4.0°
<b>Calibration loads</b> (plug and jack)	DC to ≤ 4 GHz > 4 to ≤ 10 GHz	Return Loss	≥ 38 dB ≥ 26 dB
<b>Calibration adaptors</b> (plug/plug , jack/jack, plug/jack)	DC to ≤ 4 GHz > 4 to ≤ 10 GHz	Return Loss	≥ 30 dB ≥ 26 dB
<b>Calibration adaptors RPC-3.50 to P-SMP</b> (plug/plug and jack/jack)	DC to ≤ 4 GHz > 4 to ≤ 10 GHz > 10 to ≤ 18 GHz > 18 to ≤ 26.5 GHz	Return Loss	≥ 32 dB ≥ 28 dB ≥ 23 dB ≥ 19 dB

b. The specifications for opens and shorts are given as allowed deviation from nominal model as defined in calibration certificate included with your kit.

**Declaration of calibration options**

**Factory Calibration**

Standard delivery for this kit includes a Factory Calibration. The Calibration Certificate issued reports individual calibration results, **traceable to Rosenberger standards**, national / international standards are not available. Model based standard definitions of the calibration standards are reported in Agilent/Keysight, Rohde & Schwarz and Anritsu compatible VNA format.

**Accredited Calibration**

Not available.

*For further, more detailed information see application note AN001 on the Rosenberger homepage.*

**Calibration interval**

Recommendation 12 months

**Recommended accessories**

- Rosenberger Test Port Adaptor
- Rosenberger VNA Test cable kit and Microwave Cable Assemblies

*For further, more detailed information please visit our homepage [www.rosenberger.com](http://www.rosenberger.com).*

While the information has been carefully compiled to the best of our knowledge, nothing is intended as representation or warranty on our part and no statement herein shall be construed as recommendation to infringe existing patents. In the effort to improve our products, we reserve the right to make changes judged to be necessary.

Draft	Date	Approved	Date	Rev.	Engineering change number	Name	Date
H. Babinger	25.04.16	Martin Moder	12.05.16	a00	16-s154	M. Knoll	12.05.16
Rosenberger Hochfrequenztechnik GmbH & Co. KG P.O.Box 1260 D-84526 Tittmoning Germany <a href="http://www.rosenberger.de">www.rosenberger.de</a>					Tel. : +49 8684 18-0 Fax : +49 8684 18-499 Email : <a href="mailto:info@rosenberger.de">info@rosenberger.de</a>		Page 3 / 3